

heba loading cranes Arnd Bruckhaus e.Kfm.

Kerkhagen 16 D-58513 Lüdenscheid

Phone ++ 49 / (0) 23 51 / 67 74 53 Fax ++ 49 / (0) 23 51 / 67 74 55

www.heba.eu info@heba.eu

VAT ID no.: DE813563286

Guidelines to suppliers:

Lüdenscheid, June 2015

All specifications are part of your delivery and of the agreed purchase price.

Scope of delivery with cranes:

- Crane
- Inspection book
- CE certificate
- Technical documentation with manual and parts list
- cranes with rope winch including the following parts:
 - -head roller with bolts
 - interim roller
 - loading hook with rope weight
- cranes with remote control include the following parts:
 - -control panel
 - shoulder strap for control panel
 - charger
 - -2 batteries

Shipping requirements:

- All hydraulic hoses and connections must be sealed. No oil may leak out.
- Support cylinders must be swung upwards or dismantled.
- Crane is to be mounted on wooden beams or a pallet.

Loading and unloading of the crane with a forklift must be possible.

The space required for the forks must be at least 110mm.

Substructure sample pictures:







